

XP SERIES

LMT5000

LUMBER JACK

Original Manual Multi Tool



⚠ WARNING

Read this manual before using this product.
Failure to do so can result in serious injury.
SAVE THIS MANUAL.



INDEX

- 1 - 3. Power Tool & Personal Safety
 - 4. Symbols & Technical
 - 5. Includes
 - 6 - 8. Operation
 - 9. Maintenance & Service
 - 10. Declaration
-

General Power Tool Safety Warnings

⚠ WARNING : Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term " power tool " in the warnings refers to your mains operated (corded) power tools or battery operated (cordless) power tools.

1. Work Area Safety

- a. Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- c. Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2. Electrical Safety

- a. Power tool plugs must match the outlet. Never modify the plug in any way.** Do not use any adapter plugs with grounded power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b. Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is grounded.
- c. Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- d. Do not abuse the cord.** Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e. When operating a power tool outdoors, use an extension cord suitable for outdoor use.** Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f. If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** Use of a RCD reduces the risk of electric shock.

⚠ NOTE :The term residual current device (RCD) may be replaced by the term ground fault circuit interrupter (GFCI) or earth leakage circuit breaker (ELCB).

3. Personal Safety

- a. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- b. Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c. Prevent unintentional starting. Ensure the switch is in the off position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.
- d. Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e. Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- f. Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

4. Power Tool Use and Care

- a. Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b. Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c. Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing

power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.

d. Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

e. Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tools operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.

f. Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.

g. Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

5. Battery tool use and care

a. Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.

b. Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.

c. When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.

d. Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

e. Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.




f. Always push the gear selector and turn the operating mode selector switch through to the stop. Otherwise, the machine can become damaged.

Service

Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

6. Symbols

a. Some of the following symbols may appear on this product. Study these symbols and learn their meanings. Proper interpretation of these symbols will allow for more efficient and safer operation of this product.

SYMBOL	DESCRIPTION
	Read the manual before set-up and/or use.
	Do not dispose with household waste.
	Conforms to relevant safety standards.

Technical Data:

Voltage:	20V
Speed:	5000 - 19000RPM
Oscillation:	3
Sound Level:	Lpa - 75dB Lwa - 86 dB



Includes:



1. Clamping plate
2. Accessory part
3. LED work light
4. Quick change lever
5. On / Off button
6. Handle
7. Battery (not included)
8. Speed selector
9. Saw blade
10. Spatel
11. Velcro Base
12. Sandpaper



Operation:

Adding the Sanding Paper

With the Velcro Base (11) mounted, the machine can be used as a triangular sander and sand on materials of eg wood and metal. The machine is not intended for water sanding.

Choose a sandpaper (12) with a grain size that is suitable for the job.

Use sandpaper with a small grain size for coarse sanding and sandpaper with a large grain size for finer sanding.

Press the sanding paper against the surface of the sanding sole and check that it is firm.

Make sure that the opening in the plate is placed over the tail in the sole.



Put the sanding sole against the workpiece. Give the machine time to work. It is necessary to press the sanding sole against the surface being sanded.

The triangular shape of the sandpaper gives you the opportunity to breathe into the horns with the sanding sole. If the tip of the sandpaper becomes worn, you can remove the sandpaper from the sanding sole, turn it 120 °, then put it back on.



Adding the Saw Blade

The special design of the saw blade (9) means that you can saw against edges where you cannot reach with a regular saw. The saw blade does not rotate, but oscillates. You can saw wood, plaster and other materials. Make sure that the workpiece does not contain foreign objects, e.g. nails and screws.

Make sure that the saw blade is not pressed, bent or twisted. Also pay attention so that the saw blade does not come into contact with hard materials such as metal or stone, as the outermost teeth of the saw blade can be knocked off.

Regularly remove dust, chips and sawdust from the spade.

Quick Release

Fold up the quick change lever (4) so that the pressure on the clamping plate (1) on the spindle is released.

Unscrew the flange of the spindle.

Insert the desired accessory around the spindle so that its holes or grooves match the locking pins.



The attachments can be angled in several positions depending on the nature of the task.

Lightly screw on the flange.

Be sure to turn it to fit the holes or grooves in the fitted accessory.

Fold the handle (4) all the way down again so that the clamping plate is pressed against the accessory and laser it firmly.



Insert the battery (7) on the multi tool so that it engages with an audible click.

Check that the accessory is fitted correctly. Switch on the machine on the on / off button (5).



Maintenance:



WARNING: Before any work on the machine itself, remove the battery pack from the drill.

1. Inspect bolts periodically. If the bolts loosen, tighten them immediately, or will result in serious accident.
2. Inspect tool cords periodically. If damaged, have repaired at your nearest Authorised Service Center.
3. Keep the vents clean. Clean all parts of the tool, clean dust periodically. To prevent debris from entry.
4. All service MUST only be performed by Authorised Service Center. ALWAYS use only accessories that are recommended for this tool.
5. Cleaning. Use clean cloths and mild soap to remove dirt, dust, etc.



Service:

1. In case of guarantee repair or purchase of replacement parts, always contact the qualified service center. Please supply with the appropriate service card and invoice.
2. It is outside the scope of guarantee when the tool has normal wear and tear, overloading or improper use of the tool.

CE DECLARATION OF CONFORMITY

TOOLSAVE

Unit C, Manders Ind. Est.,
Old Heath Road, Wolverhampton,
WV1 2RP.

Tel: 01902 450 470

Declares that the Multi Tool (LMT5000)
Is in compliance with the regulations included in the
Directives:2006/42/EC

EC DECLARATION OF CONFORMITY

Certificate for EC-type examination delivered by Intertek Testing Services
Ltd.,Shanghai,ETL Semko Building No.86,1198 Qinzhou Road(North),Caohejing

Development Zone,Shanghai 200233,China. (Verification No.:150300747SHA-V1)
Person who declares: Bill Evans



13.04.2021

**The
Director**



LUMBER JACK

UNIT C
MANDERS INDUSTRIAL ESTATE,
OLD HEATH ROAD,
WOLVERHAMPTON

www.Lumberjacktools.co.uk